


Awesome Mixtape

WIRELESS SPEAKER


INSTRUCTION SHEET



IN THE BOX:

- 1 x Awesome Mixtape Wireless Speaker
- 1 x Micro USB Cable
- 1 x Instruction Sheet

FUNCTIONS:



1. Micro USB Recharging Port
2. Power Switch
3. Speaker Grill

BLUETOOTH INSTRUCTION:

1. Switch the power to turn on the speaker. A prompt will sound and the indicator light will flash blue to indicate that it is in pairing mode.
2. On your mobile device, turn Bluetooth on, search for Bluetooth devices, and select "Awesome Mixtape"
3. If prompted for a password, enter 0000. The speaker will connect to your device and be ready for use.

CHARGING THE SPEAKER:

- Plug the provided micro USB charging cable into the speaker and an active computer USB port or a USB AC adapter that is plugged into an active wall outlet. The indicator LED will glow red while charging and turn off once charging has completed.
- Charging Time: 2 hours

SPECIFICATIONS:

- Bluetooth version: 5.0
- Speaker power: 1W X2
- Battery capacity: 300mAh
- SNR: ≥ 80 db
- Input: 5V 1A
- Frequency response: 150HZ~20KHZ
- Product size: 100 X 63 X 11.5 mm
- Product weight: 58g
- Material: ABS

NOTES:

1. Do not use the product in high temperature; Always keep your product away from fire. For your safety, never throw the product into fire, which may cause explosion and personal injury.
2. Do not use the product near high-voltage wire or electronic apparatus. Please take proper safety measures when using the product in terrible weather conditions.
3. Do not use the product near water or any high-humidity environment, which may damage the product.
4. The product is not designed for use in or near any strong magnetic field, which may damage the product.
5. The speakers may not work properly due to wrong operation or low power. You can power on again or charge the speakers.
6. If the speakers are not paired, they will go into sleep mode after 20 minutes. Power on the speaker to use again.